

# SURE STIK PRESSURE SENSITIVE CARPET TAPE

## Read Complete Instructions Prior To Installation:

1. The floor must be clean and free of dust, dirt, and debris.
2. Position carpet in room, square and align carpet to the room area. **For rooms without seams, move to step 8.**
3. If seams are present, cut carpet edges perfectly straight for the best seam. Use seam sealer on both edges of the carpet backing to prevent raveling and delamination. Allow sealer to dry 8-10 minutes.
4. Position the carpet and seam edges (butted together) in their final location. Use a pen or pencil to mark a line down the center of the seam onto the floor.
5. Roll or fold the seam edges back, and using the line as the center, peel off the crepe paper liner side of the tape and adhere tape to the floor using hand and/or foot pressure.
6. Roll or fold the seam edges back again, remove second smooth white release liner from the full seam length. Dropping one edge onto the tape, press it down into the adhesive. Drop the second edge onto the tape, taking care to carefully position the second edge so it is butted against the first edge. Work in short sections for best results. May be advantageous to start from center and work outward.
7. Roll or fold the carpet back toward the seam from both directions exposing the floor for further tape placement.
8. Roll or fold the carpet back to expose the floor for tape placement.
9. Cut and lay lengths of Sure Stik Tape:
  - a) To fit to the perimeter of the room at the base of the wall;
  - b) In the central area of the room(s), lay parallel strips 18" – 24" apart;
10. Peel off crepe paper side of the tape and adhere tape to the floor using hand or foot pressure. Remove the remaining top liner and roll the carpet over the tape, insuring no wrinkles or fullness are present in the carpet. Work outward to the perimeter walls.
11. Press the carpet tight into the floor-wall at a 90° angle. Use a tool to form a crease in the carpet to insure a tight 90° fit around the room(s).
12. Use a sharp utility knife to cut the perimeter carpet. Hold the knife at a 45° angle and firmly cut the carpet.
13. Trim any carpet tufts or strands of fiber to insure a clean perimeter look.